



UNIVERSAL DECAP DIE

The decap pin should extend approximately 1/4" below the bottom of the die. Screw the die into the press until there is a gap between the bottom of the die and the shell holder of about 1/16" when the press ram is in the "up" position. Set the die lock ring and you're ready to decap.

WARNING:

Do not decap live primers!

Got a question?

Customer Service 1-530-538-2699 (US or Canada) or
visit our website at www.RCBS.com

RCBS
605 ORO DAM BLVD EAST
OROVILLE, CA 95965

7200498/0725